

GRILLIPUT PORTABLE GRILL

Grill on the go! Bring it backpacking, boating or on the beach—the Grilliput Duo is lightweight and assembles quickly. Use it to grill over a FireBow!™ filled with fuel and cook



DETAILS

Grill on the go! Bring it backpacking, boating or on the beach—the Grilliput Duo is lightweight and assembles quickly. Use it to grill over a FireBow!™ filled with fuel and cook enough food for 2–3 people. Crafted from high-quality stainless steel, it's beefy, beautiful, easy to clean and deconstructs like a minimalist's dream. It comes apart in seconds; all pieces fit together neatly in one of the grill's side rails.

UCO Grilliput Portable Camping BBQ Grill & Firebowl



FEATURES

- Collapsible grill is perfect size to grill food for 2-3 people.
- Constructed from durable stainless steel.
- Cleaning groove for soiled grill bars.
- Grill parts fit inside stainless steel tube for easy and compact storage.
- Bail for hanging in storage.
- Includes 1 thick tube with a stopper, 1 thin tube with a cleaning groove, 2 outer grill rods with hooks and threads, 10 grill rods, 4 grill feet.
- Dishwasher safe.

PRODUCT SPECIFICATIONS

- Dimensions-packed: 11.4" x 0.9" (29 cm x 2.2 cm)
- Dimensions-bbq area: 9.1" x 10.2" (23 cm x 26 cm)
- Weight: 19.8 oz. (560 g)

CARE & INSTRUCTIONS

- Grilliput is suitable for dishwashers.
- In case of heavy soiling, scour with Scotchbrite (grit size 400) in the grinding direction.
- To care for Grilliput, occasionally apply a spray-on stainless steel cleaner and wipe off with a clean soft cloth.

Assembly Instructions:

1. Unscrew the stainless steel tube and remove all the grill elements:

- 1 thick tube with a stopper
 - 1 thin tube with a cleaning groove
 - 2 outer grill rods with hooks and threads
 - 10 grill rods
 - 4 grill feet
2. Place both tubes with the threaded holes for the feet facing upwards. The holes of the thick tube and the grooves of the thin tube must be opposite each other.
 3. The outer grill rods with a thread are pushed through the thin tube and fixed to the thick tube with an initial single turn.
 4. Screw the stopper back on to the thick tube (to avoid it being lost).
 5. Insert the 10 grill rods.
 6. Screw the outer grill rods with the hooks fully into the thick tube.
 7. Screw the 4 grill feet tight.
 8. Turn the grill over and you're ready to use it.

WARNING: Intended only for adults. Keep away from children and pets. Never leave grill unattended. Do not use in a confined space. Not suitable for camping gas stoves. Ensure a secure and stable position. Load bearing capacity up to 3.3 lbs. (1.5 kg) maximum. Beware of flying sparks. Always respect nature and the environment.

SPECS

No.	GR-1
Description	Grilliput Portable Grill
Product Group Name	Camp Kitchen
Item Category Name	Grills
Item Category Code	UCO-COOK
Net Weight	1.3